



Acrovyn®

Wall Protection Systems Care & Maintenance

Any Acrovyn wall covering or profile products (including Chameleon™ Collection) can be cleaned by using the following instructions:

1. Light soil, crayon, lipstick, blood and other mild staining agents can be removed using a Mr. Clean® Magic Eraser™ with water or household cleaners such as Fantastik®, Formula 409®, or equivalent product. Following use of the cleaner, the cleaned surface should be “rinse wiped” with clean water and wiped dry to remove any remaining soap residue.
2. Stubborn stains such as ball point pen, permanent marker, dry erase marker and shoe scuffs can be removed by using denatured alcohol, isopropyl alcohol or ethyl alcohol in concert with a Mr. Clean® Magic Eraser™. When using alcohol, care must be taken not to permanently mar the Acrovyn surface. Also, when using the Mr. Clean® Magic Eraser™ always scrub with the grain of the Acrovyn. Always follow with soap and water to remove any residue.
3. To add additional protection and luster to the cleaned surface, a coat of spray wax or vinyl enhancer may be applied. Recommended brands are Johnson Wax®, Pledge® or Armor All®.

Care must be exercised when using fingernail polish remover or acetone to remove ink stains. These chemicals will temporarily soften the surface of the Acrovyn. Moisten a cotton cloth and work in small areas. Immediately remove cleaner with straight water.

Do not use methyl ethyl ketone (MEK), cleaners containing MEK, bleach or any other cleaners containing harsh solvents on Acrovyn sheets, panels or profiles. Powdered cleansers are not recommended as they are abrasive and tend to leave a residue if not utilized properly.

Do not use Scotch-Brite™ pads, steel wool or cleaning pads such as Brillo® or S.O.S.® on Acrovyn sheets, wall panels or profiles.



Acrovyn®

Renaissance™ Collection Care & Maintenance

Renaissance™ Wood Collection

All C/S wood components can be cleaned using the following instructions:

1. Chips, dents and deep scratches can be repaired by filling with the Fil-Stik or Patchal Pencil. Either rub in or press in, then remove excess. Color may be applied with the Instant Touch-up Marker or Pro-Mark II Marker.
2. Surface scratches, scuffs or rubbed edges may be re-colored with the Instant Touch-up Marker or Pro-Mark II Marker.
3. Dust and light soil can be removed by using mild soap and water or household cleaners such as Fantastik®, Formula 409® or similar products. Soft cloths/cleaning towels are recommended during the cleaning process.

Do not wax the handrail.

Do not use solvent-based cleaners on wood.

Renaissance™ Metal Collection

All C/S stainless steel and aluminum components can be cleaned using the following instructions:

1. Dust and light soil can be removed by using mild soap and water or household cleaners such as Fantastik®, Formula 409® or similar products. Soft cloths/cleaning towels are recommended during the cleaning process.
2. Stainless steel and aluminum components will easily maintain their brilliant appearance using the products mentioned and occasionally polishing with a quality metal cleaner such as Maas® or Brasso®.
3. Stubborn stains can be removed by using isopropyl alcohol, acetone or a thinner. Our experience has shown that a solvent is very seldom needed when cleaning stainless steel or aluminum.

Do not use abrasive cleaners, Scotch Brite™ pads or steel wool.